


# Wiring Diagrams

## MULTIFLOW SMB 220V-240V SINGLE PHASE


### FIXED SPEED CONNECTION



# Wiring Diagrams

## MULTIFLOW SMB 220V-240V SINGLE PHASE C/W EL31 / EL61 / EL101

**VARIABLE SPEED CONNECTION**  
**CONTROLLER TYPES: 149-EL31**  
**149-EL61**  
**149-EL101**




# Wiring Diagrams

## MULTIFLOW SMB 220V-240V SINGLE PHASE C/W TC

### VARIABLE SPEED CONNECTION


CONTROLLER TYPES: 149-TC12  
 149-TC14  
 149-TC18  
 149-TC110  
 149-TC112  
 149\*TC116




# Wiring Diagrams

## MULTIFLOW SMB 380V-440V THREE PHASE

### FIXED SPEED STAR CONNECTION




### FIXED SPEED DELTA CONNECTION



# Wiring Diagrams

## MULTIFLOW SMB 380V-440V DELTA THREE PHASE C/W TC

**VARIABLE SPEED  
DELTA CONNECTION  
CONTROLLER TYPE: 149-TC33  
149-TC35  
149-TC310**



# Wiring Diagrams

## MULTIFLOW SMB 380V-440V STAR THREE PHASE C/W TC

**VARIABLE SPEED CONNECTION**  
**CONTROLLER TYPES: 149-TC33**  
**149-TC35**  
**149-TC310**

